



## BIOCYCLE SYSTEM OPERATING WATER LEVELS

NTS

### INSTALLATION

1. EXCAVATE A 10' x 10' x 10' DEEP HOLE FOR BIOCYCLE SYSTEM.
2. PLACE A MINIMUM OF 4" SAND OR GRAVEL FOR LEVELING COURSE IN THE BOTTOM OF THE EXCAVATION. COMPACT AS NECESSARY.
3. PLACE 4 SHEETS OF 2' x 8' x 2" DIRECT BURIAL RIGID INSULATION ON TOP OF COMPACTED THAT INSULATION COURSE IS LEVEL IN ALL DIRECTIONS.
4. BACKFILL AROUND TANK UP TO INVERT OF 4" INFLUENT AND 1-1/4" EFFLUENT LINES WITH FREE FLOWING MATERIAL FREE OF LARGE STONES OR BOULDERS.